



miestna organizácia zaoberajúca sa likvidáciou elektroodpadu./Waste equipment must not be collected separately or disposed of with household waste because it may contain components hazardous to the environment or health. Use or waste equipment may be dropped of free or charge at the point of sale, or at any distributor which sales equipment of identical nature and function. Dispose of product at a facility specializing in the collection of electric waste. By doing so, you will protect the environment as well as the health of others and yourself. If you have any questions, contact the local waste management organization. We shall undertake the tasks pertinent to the manufacturer as prescribed in the relevant regulations and shall bear any associated costs arising.

**CE** Výrobok je v súlade s platnými európskymi smernicami a bola vykonaná metóda hodnotenia zhody týchto smerníc./The product complies with the applicable European directives and the conformity assessment method of these directives has been implemented.



**POUŽITIE/USE:** Nepoužívajte výrobok bez dozoru! Výrobok nie je hračka, nepatrí do rúk deťom! Tento výrobok používajte na dekoratívne osvetlenie, nie je určený na osvetlenie domácnosti. Výrobok je zložený zo svetelných diód (LED), ktoré sú nevymeniteľné! Vyberte výrobok z obalu a skontrolujte, či nie je poškodený. Vložte 3 ks AAA batérií a pomocou vypínača dekoráciu rozsviette alebo zhasnite. /Do not operate with the product without supervision. The product is not a toy, Keep out of reach of children. The product is intended to be used as ornamental lighting and is not suitable for illuminating domestic premises. This product consists of Light Emitting Diodes (LED's) which cannot be accessed or replaced. Remove the product from the packaging taking care not to damage or twist the wires. To operate, insert 3 pcs AAA batteries and use the switch to turn the product on or off.

**Batérie/Batteries:** Dodržiavajte správnu polaritu. Ak batérie dlhší čas nepoužívate vyťahnite ich. Vytečené alebo poškodené batérie môžu spôsobiť popáleniny kyselinou pri kontakte s pokožkou, pri manipulácii s nimi používajte vhodné ochranné rukavice. Nenechávaj-



te v dosahu detí, nedemontujte, neskratujte ani nevhadzujte do ohňa. Nikdy nenabíjajte nenabíjateľné batérie. Existuje riziko výbuchu! / Observe the correct polarity. If batteries not use for a long time, pull them out. Leaking or damaged batteries can cause burns if exposed to the skin, use suitable protective gloves when handling them. Keep out of reach of children, do not disassemble, shorten or throw into the fire. Never charge non-rechargeable batteries. There is a risk of an explosion!

**Vysvetlivky symbolov/Explanation of symbols:**  
 Výrobok nevyhadzujte do bežného domového odpadu, separujte oddelene lebo môže obsahovať súčasti nebezpečné pre životné prostredie alebo zdravie ľudí. Za účelom správnej likvidácie výrobku ho odovzdajte na mieste predaja, kde bude prijatý zdarma alebo u predajcu, ktorý predáva identický výrobok vzhľadom na jeho ráz a funkciu. Výrobok môžete odovzdať aj miestnej organizácii zaoberajúcej sa likvidáciou elektroodpadu. Týmto chránite životné prostredie, zdravie ostatných aj svoje. Prípadne otázky Vám zodpovie predajca alebo



Trieda ochrany III./Protection class III.



Časovač/Timer